



SnapCam LE – FW installation notes:

Download SnapCam LE Firmware from our Download Page.

- Drag and Drop file "FPUUPDATE.DAT" onto the memory card.
- Power on the camera.
- Hold both the shutter and power button for approx. 8-10 secs so that the camera resets.
- Repeat the above and the process should begin.

If the Orange battery LED blinks, you will need to charge the device before attempting again.

If you experience any issues regarding the installation process, please contact support at: ioncamera.com/support/contact-us/